




BREAKSAFE™ AMPULE OPENER


Catalog Number F38952-0000

Patent Pending



Note: Inserts should be empty when installing or removing from the ampule opener


INSTALLING DESIRED INSERT:



Recessed openings

1. Hold the desired insert (1ml, 2ml, 5ml, 10ml) so that the volume specification is facing the front of the ampule opener and the recessed openings on the back edge are towards the back of the ampule opener.
2. Place the insert into the opening and then tilt the insert back at a 45° angle inserting the back edge under the "immobilizing lip" located on the inner backside of the ampule opener.
3. Push down gently on the front of the insert where the volume is specified until it is locked into place and there is no movement.

USING THE BREAKSAFE® AMPULE OPENER:



1. Insert up to three ampules that correspond to the specified volume.
2. Lower the lid until it is secure around the neck of the ampules.
3. With one hand push down on the Scienceware® logo located on the lid until the ampules break.

To discard used ampules, hold the lid of the ampule opener open and invert the unit over a glass disposal box or other appropriate receptacle.

REMOVING AMPULE HOUSING:



1. Holding the ampule opener in one hand, use the fingers of your other hand to reach under opener and behind the three columns of the insert where the ampules would be contained.
2. Pull forward on columns until the back edge of the insert is no longer under the "immobilizing lip".
3. Grasp the front edge of the insert where the volume is specified and lift to remove the insert from the ampule opener.

Help others choose the right product. Write a review at www.belart.com

661 Route 23 South, Wayne, NJ 07470

TEL: 973-694-0500 • FAX: 973-694-7199 • www.belart.com

Bel-Art – SP Scienceware assumes no obligation or liability for any advice furnished by it, or for results obtained with respect to these products.

All such advice is given and accepted at the buyer's risk.

© 2020. All Rights Reserved.

Bel-Art® – SP Scienceware® is a division of SP Industries, Inc.



938952009 - Rev. 2

